


Removing and installing dust and pollen filter

Removing

- Remove footwell cover -1- on front passenger side.
- Remove baffle plate -2- from heater unit
→ Fig..
- Release cover -3- in direction of arrow.
- Remove dust and pollen filter from heater unit downwards.

Installing



Install in reverse order.



Note

Observe installation position of dust and pollen filter.

