

POLO

Current Flow Diagram

No. 54 / 4

Operating unit for window regulator in driver door, Driver door control unit, Onboard supply control unit

- E39 - Rear window regulator isolation switch
- E40 - Front window regulator switch
- E53 - Rear left window regulator switch, in driver door
- E55 - Rear right window regulator switch, in driver door
- E81 - Front right window regulator switch in driver door
- E512 - Operating unit for window regulator in driver door
- J386 - Driver door control unit
- J519 - Onboard supply control unit
- L53 - Window regulator switch illumination bulb
- T10j - 10-pin connector
- T16g - 16-pin connector
- 303 - Earth connection 3, in drive side door wiring harness

R81 - Connection 1 (58d), in driver side door wiring harness

