


Removing and installing air intake grille - vehicles without auxiliary radiator (left-side)

Special tools and workshop equipment required

- ♦ Hook -T40207-



Removing

- Insert hook -T40207- in opening -1- and pull air intake grille (bottom) -2- out of bumper cover -arrow-.

Installing

Install in reverse order of removal.

